

Connecting MyoVision Hardware

Last Modified on 03/26/2021 3:46 pm PDT

This article will guide you through understanding the different pieces of your MyoVision system, setting up the MyoVision hardware, and will help you familiarize yourself with the different parts of each MyoVision device.

Go to training.myovision.com for the online training course.

Packing List and Supplies

When you receive your MyoVision system, read through the packing list and make sure that all the items listed have been included with your system.

Click through the tabbed menu below to see what items should be included with each device.

ScanVision FlexVision DynaVision SoloVision PhysioMonitor

After you have verified that everything listed in the Packing List was included with your order, you are ready to begin connecting your MyoVision System to your computer.

Setting Up Your Devices

The handheld devices transmit data to your SoloVision or PhysioMonitor. In order for the devices to communicate, they will need to be bound. If you purchased your devices directly from MyoVision, your handheld devices will already be bound to your SoloVision or PhysioMonitor unit.

Click through the tabbed menu below for instructions on how to set up each type of device.

ScanVision FlexVision DynaVision VisionPort2 ThermoVision USB C-5000
SoloVision PhysioMonitor
